

For anything outside of the scope of this document please contact Flowfit or a qualified hydraulic engineer. This is provided in good faith and without liability and does not form part of any contract.

Standard Information

Hydraulic adaptors are critical components in hydraulic systems, enabling connections between hoses, pipes, or equipment. Proper installation and handling are essential to ensure system efficiency and safety.

Safety Precautions

1. Personal Protective Equipment (PPE):
 - Wear safety gloves to protect against fluid exposure and sharp edges.
 - Use safety goggles to shield your eyes from potential fluid sprays.
 - Use protective footwear in case of dropped components.
2. Pressure Awareness:
 - Always depressurize the hydraulic system before starting installation or maintenance.
 - Verify system pressure ratings and ensure adaptors match the system's specifications.
3. Leakage and Contamination:
 - Inspect adaptors for signs of damage, such as cracks, deformities, or corrosion, before use.
 - Ensure all components are clean and free from dirt, debris, or contaminants.
4. Chemical Compatibility:
 - Verify that the adaptor material is compatible with the hydraulic fluid used in the system.



Pre Installation Checks

- Gradually pressurize the system while monitoring for leaks or unusual noises.
- Re-inspect all connections under full operating pressure.
- Address leaks immediately by depressurizing the system and retightening or replacing components as needed.

Installation Procedure

1. Preparation:

- Confirm that the adaptor's type, size, and pressure rating match the system requirements.
- Clean all mating surfaces and threads to remove dirt and grease.

2. Thread Sealing:

- Apply thread sealant or Teflon tape to male threads if required. Avoid over-application, as excess material can contaminate the system.
- For O-ring face seal (ORFS) fittings, inspect and lubricate the O-ring with a compatible lubricant.

3. Align and Connect:

- Align the adaptor properly to avoid cross-threading or undue stress on the connection.
- Thread the adaptor by hand to prevent misalignment. Once hand-tight, use a wrench to tighten further.

4. Torque Application:

- Use a torque wrench to tighten the connection to the manufacturer's specified torque values. Over-tightening can damage threads and O-rings, while under-tightening can cause leaks.

5. Verify Installation:

- Double-check that all connections are secure and correctly aligned.
- Inspect for visible gaps, misalignments, or signs of stress.



Maintenance and Inspection

1. Routine Inspections:

- Inspect adaptors regularly for wear, corrosion, or deformation.
- Check for fluid leaks and ensure fittings remain tight.

2. Component Replacement:

- Replace adaptors showing signs of damage or wear promptly.
- Use only genuine parts from the system manufacturer.

3. System Cleaning:

- Keep the hydraulic system clean to prevent debris from damaging the adaptor or system components.



Common Mistakes to Avoid

- Using incorrect adaptors: Always ensure adaptors are rated for the system's pressure and fluid type.
- Over-tightening threads: This can strip threads or damage seals.
- Skipping system depressurization: Pressurized systems can cause serious injury.
- Reusing damaged components: Always replace worn or damaged adaptors.

Following these safety guidelines ensures that hydraulic adaptors are used effectively and safely. Always prioritize safety by adhering to protocols and maintaining the equipment in optimal condition.