

October 2020



[noForth website](#)

Sipeed Longan Nano board (RISC-V) with noForth r(cv)

1. Sipeed Longan Nano board
 - i/o port connections
 - Connectors
 - Hardware
2. i/o Ports
 - Port addresses
 - Port register offsets
 - Values for port control (CRL/CRH)-Registers
3. RS232/USB driver
4. noForth memory map (all variants)
5. Interrupt vector table

In this text we refer to these two documents:

- GD32VF103_Datasheet_Rev1.0.pdf
- GD32VF103_User_Manual_EN_V1.2.pdf

1. Sipeed Longan Nano board



Sipeed Longan Nano board (with RISC-V GD32VF103CBT6)

Core Sub-Architecture: RISC-V IMAC

- Anratek: Sipeed Longan Nano board
- Seed: Sipeed Longan Nano board

i/o port connections


<u>Port A</u>	<u>Port B</u>	<u>Port C</u>
PA.0 - BOOT0	PB.0 - ...	PC.0 - ...
PA.1 - LED	PB.1 - ...	PC.1 - ...
PA.2 - LED	PB.2 - ...	PC.2 - ...
PA.3 - ...	PB.3 - JTDO	PC.3 - ...
PA.4 - ...	PB.4 - ...	PC.4 - ...
PA.5 - ...	PB.5 - ...	PC.5 - ...
PA.6 - ...	PB.6 - ...	PC.6 - ...
PA.7 - ...	PB.7 - ...	PC.7 - ...
PA.8 - TXD	PB.8 - ...	PC.8 - ...
PA.9 - RXD	PB.9 - ...	PC.9 - ...
PA.10 - ...	PB.10 - ...	PC.10 - ...
PA.11 - ...	PB.11 - ...	PC.11 - USB
PA.12 - ...	PB.12 - TF_CS SD	PC.12 - USB
PA.13 - JTMS	PB.13 - SPI1_SCK SD	PC.13 - LED
PA.14 - JTCK	PB.14 - SPI1_MISO SD	PC.14 - OSC32_IN
PA.15 - JTDI	PB.15 - SPI1_MOSI SD	PC.15 - OSC32_OUT



Learn more at:
<https://longan.sipeed.com>

NANO PINOUT

Power
GND
Control
Physical Pin
Port Pin
SPI Pin
I2C Pin
Serial Pin
Analog Pin
Debug Pin
Timer Pin
USB Pin
I2S Pin
CAN Pin
Clock Pin
Remap Pin
Ports



Twitter, Github
[@kprasadvnsi](https://github.com/kprasadvnsi)

SiPEED
<https://sipeed.com>

Connectors

- J1 = i/o PA, PB, 3V3, 5V and GND
- J2 = i/o PA, PB, PC, RESET and VBAT
- J3 = RS232/JTAG, 3V3 & GND
- J4 = USB-C Programming connector
- J5 = LCD connector
- J6 = Micro SD connector

Hardware

- Three color led on PA.1, PA2 and PC.13
- Switch BOOT0 on PA.0
- Switch for boot mode setting
- Reset switch RESET
- JTAG/Serial 8-pin connector
- LCD connector
- Micro SD connector
- 32.768 crystal

2. i/o ports

Port addresses

The GD32VF103CBT6 port registers are memory mapped.
First the base addresses for the i/o-ports:

Port-A = 40010800
Port-B = 40010C00
Port-C = 40011000


Port register offsets

<u>Label - PA/PB/PC</u>	<u>-</u>	<u>Function</u>
x_CRL	00	Control reg. P0 to P7
x_CRH	04	Control reg. P8 to P15
x_IDR	08	Input data reg.
x_ODR	0C	Output data reg.
x_BSRR	10	Set/Reset reg. P0 to P15
x_BRR	14	Reset reg. P0 to P15
x_LCKR	18	Lock register

Values for port control (CRL/CRH)-Registers

- 0: Analog Input
- 1: Output Push/Pull, 10 MHz
- 2: Output Push/Pull, 2 MHz
- 3: Output Push/Pull, 50 MHz
- 4: Floating Input (Reset state)
- 5: Open-Drain Output, 10 MHz
- 6: Open-Drain Output, 2 MHz
- 7: Open-Drain Output, 50 MHz
- 8: Input with pull-up / pull-down
- 9: Alternate Function, Push/Pull, 10 MHz
- A: Alternate Function, Push/Pull, 2 MHz
- B: Alternate Function, Push/Pull, 50 MHz
- C: Reserved
- D: Alternate Function, Open-Drain, 10 MHz
- E: Alternate Function, Open-Drain, 2 MHz
- F: Alternate Function, Open-Drain, 50 MHz

The reset value for all port control registers is 44444444. More info in the GD32VF103_User_Manual_EN_V1.2.PDF (page 101).



3. RS232/USB driver

The USB chip on the SEED board is a dongle with the PL2303TA Prolific USB-chip. This chip needs a specific driver under Windows XP/7/8/10. Unzip this file and execute [PL2303-Prolific_DriverInstaller_v1200.exe](#). The default baudrate for the GD32VF controller is 115200 baud.

4. noForth memory map (all variants)

RAM 20000000 - 20007FFF

```

20000000 HOT          \ warm Udata (max 200 bytes)
... UHERE             \ start of free Uspace
20000200 FLYBUF       \ FLYER buffer (400 bytes)
20000600 FLYBUF/
20000680 S0            \ data stack (80 bytes down)
20000880 R0            \ return stack (200 bytes down)
20000880 TIB           \ input buffer (80 bytes)
20000900 TIB/
20000900 SYSBUF        \ TIDY buffer (400 bytes)
20000D00 SYSBUF/       \ start of allotted RAM
... HERE               \ start of free RAM space
20008000 RAMBORDER

```

FLASH ROM 00000000 - 0001FFFF

```

0000    interrupt vectors
0200    FROZEN      \ cold Udata (max 200 bytes)
0400    ORIGIN       \ start of dictionary
...     CHERE        \ start of free dictionary space
1F000   BORDER

```

- BORDER and RAMBORDER are changeable uvalues (Udata).
- Udata is saved to FROZEN by FREEZE .
- At start-up (and reset or COLD) noForth moves the Udata at FROZEN to HOT .

5. Interrupt vector table

See GD32VF103_User_Manual_EN_V1.2.PDF for more details (page 93-100).

```
0000 - Reset ( Jump opcode )
000C - CLIC INT SFT
001C - CLIC INT TMR
0044 - CLIC INT BWEI
0048 - CLIC INT PMOVI
004C - WWDGT interrupt
0050 - LVD from EXTI interrupt
0054 - Tamper interrupt
0058 - RTC global interrupt
005C - FMC global interrupt
0060 - RCU global interrupt
0064 - EXTI Line0 interrupt
0068 - EXTI Line1 interrupt
006C - EXTI Line2 interrupt
0070 - EXTI Line3 interrupt
0074 - EXTI Line4 interrupt
0078 - DMA0 channel0 global interrupt
007C - DMA0 channel1 global interrupt
0080 - DMA0 channel2 global interrupt
0084 - DMA0 channel3 global interrupt
0088 - DMA0 channel4 global interrupt
008C - DMA0 channel5 global interrupt
0090 - DMA0 channel6 global interrupt
0094 - ADC0 and ADC1 global interrupt
0098 - CAN0 TX interrupts
009C - CAN0 RX0 interrupts
00A0 - CAN0 RX1 interrupts
00A4 - CAN0 EWMC interrupts
00A8 - EXTI line[9:5] interrupts
00AC - TIMER0 break interrupt
00B0 - TIMER0 update interrupt
00B4 - TIMER0 trigger and channel commutation interrupts
00B8 - TIMER0 channel capture compare interrupt
00BC - TIMER1 global interrupt
00C0 - TIMER2 global interrupt
00C4 - TIMER3 global interrupt
00C8 - I2C0 event interrupt
00CC - I2C0 event interrupt
00D0 - I2C1 event interrupt
00D4 - I2C1 event interrupt
00D8 - SPI0 global interrupt
00DC - SPI1 global interrupt
00E0 - USART0 global interrupt
00E4 - USART1 global interrupt
00E8 - USART2 global interrupt
00EC - EXTI line[15:10] interrupts
00F0 - RTC alarm from EXTI interrupt
00F4 - USBFS wakeup from EXTI interrupt
0114 - TIMER4 global interrupt
0118 - SPI2 global interrupt
011C - UART3 global interrupt
0120 - UART4 global interrupt
0124 - TIMER5 global interrupt
0128 - TIMER6 global interrupt
012C - DMA1 channel0 global interrupt
0130 - DMA1 channel1 global interrupt
0134 - DMA1 channel2 global interrupt
0138 - DMA1 channel3 global interrupt
013C - DMA1 channel4 global interrupt
0148 - CAN1 TX interrupt
014C - CAN1 RX0 interrupt
0150 - CAN1 RX1 interrupt
0154 - CAN1 EWMC interrupt
0158 - USBFS global interrupt
```