



The CAD detail library is intended to provide general framing details only and does not replace the judgments and designs of a qualified architect and/or engineer. The details are provided as a starting tool to assist the user in creating and detailing cold-formed steel framing construction details. Each detail including accompanying text must be thoroughly evaluated and approved by a qualified architect or engineer.

Engineering Services: (877) 832-3206


Technical Services: (888) 437-3244



"BUTTERFLY" CUT SPAZZER BAR AND BEND LEGS 90°. USE (2) #10-16 SCREWS IN EACH LEG (LEGS TO BE A MIN. 1-1/2" LONG).

SPAZZER BAR FLY CLIP (SFLY) W/ (4) #10-16 SCREWS

AT ALL 20ga. STUDS AND ALL LOAD BEARING STUDS



USE (2) #10-16 SCREWS AT EACH STUD AS SHOWN

SPAZZER BAR GUARD (SPBG) W/ (2) #10-16 SCREWS

SPAZZER GROMMET (SPGR)

SPAZZER BAR IS NOT SUITABLE FOR WALL STUDS DEEPER THAN 8"

EACH END OF LATERAL BRACING MUST BE RIGIDLY FIXED OR OTHERWISE PREVENTED FROM HORIZONTAL MOVEMENT.

1 ClarkDietrich SPAZZER 5400 LATERAL BRACING